

## **AUTO DOOR PILE SEAL**


(A) Auto Door Seal shuts off wind, rain, dust and noise. Auto Door Seal is very helpful to energy savings.

## (B) SPECIAL FEAUTRE

- 1. Pile seal is soft and it makes door easy to operate.
- 2. Film (double fins) in the center of seal makes better airtightness and watertightness.
- 3. Special treated pile has excellent water-resistant and restoring force.
- 4. Easy one-touch installation makes easy to clean seal.

## (C) INSTALLATION

- 1. Cut Auto Door Seal according to height of door, and attach it to the door center of both sliding automatic.
- 2. Cut pile height to meet the gap if pile height is too high, to avoid too much friction between frame and door.





## SCHLEGEL PTY. LIMITED

Head Office: 44-48 Riverside Road, Chipping Norton NSW 2170 Telephone: (02) 726 8477 Fax: (02) 724 7454

Interstate Offices, New Zealand & Singapore

**Queensland:** Telephone: (075) 96 5626 Fax: (075) 96 5386 **Victoria:** Telephone: (03) 894 2713 Fax: (03) 894 2729

Agent: South Australia: Umcos Trading Phone: (08) 212 1700 Fax: (08) 231 1643 Western Australia: Telephone (09) 307 4922 Fax: (09) 307 4923

Agent: New Zealand: Dynex Extrusions Phone: (09) 867 144 Fax: (09) 89 4588

Singapore: Telephone: (65) 3449288 Fax: (65) 3448333